



1. The two seals are pressed into the Upper Bearing Cap.
2. The bearing is pressed into the upper bearing housing.
3. The cap threads into the upper bearing housing. Standard right hand threads.
4. The bearing housing is threaded onto the shaft frame. Standard right hand threads.
5. The prop shaft is a slip fit into the bearing.